



For instructions related to trim panel, instrument cluster and radio removal refer to the vehicle specific service manual.





Install Window Sticker

Apply Window Sticker to the lower rear of the driver's side window. It should be visible from the outside of the vehicle.



L.E.D. Pattern	L.E.D. Description	
Green LED not flashing	The ignition has not been turned on	
Green LED off for 1 second	GPS module has power and signal is valid, Cell modem is powered, ignition is ON	
Green LED off for 3 seconds	GPS module has power and signal is valid, Cell modem is powered, ignition is OFF	
Red LED blinks 1 time	The modem is not detecting a SIM card	
Red LED blinks 2 times	The modem is not detecting a cellular signal	
Red LED blinks 3 times	The GPS receiver is not tracking any satellites	
Red LED blinks 4 times	The modem has no cellular signal and GPS is not tracking any satellites	
Red LED blinks 5 times	The modem is not detecting a SIM card and GPS is not tracking any satellites	
Red LED blinks 6 times	The modem is not responding and may be defective	
Red LED blinks 7 times	The modem is not responding and GPS is not tracking satellites	

Note: The Diagnostic Test LED built into the control module will blink Green (off 1 second/on 1 second) indicating the control module is working properly.

Installation Element	Best Practice	Unacceptable Practice
Module Placement & Mounting	Under dash padding where it is not visible or easily accessible with the label facing up	On top of dashboard, under metal objects, inside of engine compartment, or anywhere visible

Control module to be located from the center of the instrument panel (area around and above the radio) to the driver's side of the vehicle only (area around and forward of the instrument cluster). Control module should never be located on the passenger side of the instrument panel or around the passenger air bag.

This information is provided to assist with installation of certain features available on the Guidepoint device and may contain outdated or incorrect information. It is the technician's job to verify all wires being used and connect them properly. Guidepoint is not responsible for any damage that may occur due to improper testing and/or installation of components related to this installation supplement. If you feel that the information contained in this supplement is incorrect, please contact Guidepoint Technical Support at 1.877.477.3710.