

10/05/2016


Installation Instructions

Strut Tower Caps

2005 - 2016 LA, LC, LD, LX Platforms

Part Number 77072464

www.mopar.com



Call out	Description	Qty.	Service Part (Y/N)	Part Number
1	STRUT TOWER CAP	2	Ν	343027CL
2	WASHER, RUBBER	4	Ν	21713
3	WASHER, STEEL	4	Ν	1-3029
4	I-SHEET (this document)	1	Ν	K6862686

For technical assistance regarding MOPAR Performance Accessories, please call toll-free 1-888-528-HEMI (528-4364).

© 2016, Chrysler Group LLC. MOPAR and Hemi are registered trademarks of Chrysler LLC. All rights reserved. K6862686

1

IMPORTANT:

Read and understand these instructions BEFORE attempting to install this product.

1) Getting Started

- a) If engine has run within the past two hours, open the hood and allow it to cool down.
- b) Make sure the vehicle is parked on a level surface.
- c) Set the parking brake.
- d) Open the Strut Tower Cap Kit and make sure all parts are included.

2) Installation of the Strut Tower Caps



1. Locate the production strut caps and remove with a plastic trim tool. Verify there are 7-8 threads on the strut tower to install the new MOPAR Strut Caps.



2. Install one (1) Steel Washer

10/05/2016 © 2016, Chrysler Group LLC. MOPAR and Hemi are registered trademarks of Chrysler LLC. All rights reserved.

2

www.mopar.com



3. Install one (1) Rubber Washer



4. Carefully thread the cap onto the shock tower and hand tighten until snug. The gap between the strut frame and the Strut Tower Cap should be similar to image. Additional Washers are provide for adjustment and variation.

Optional: Use MOPAR Lock & Seal Adhesive P/N: 04318031

Shown without MOPAR Strut Bar



3) Re-assemble the vehicle

10/05/2016

a) Inspect all MOPAR STRUT TOWER CAP components proximity to A/C lines, dip sticks, and hoses for ample clearance.

- b) Tighten all fasteners to the appropriate specifications.
- c) Inspect the engine bay for any loose tools.
- d) Start the engine and allow it to idle, and then perform a final inspection before driving the vehicle.
- e) Drive the vehicle and note any noises and check for tightness. If adequate clearance is not realized, a knocking noise could result shim up caps with the additional washer(s) as needed.
- f) Periodically check Strut Tower Caps for tightness.



Shown with MOPAR Strut Bar

K6862686

3